

The Consumer Guide to Coriolis Mass Flowmeters

*Seminar Presented by
David W. Spitzer
Spitzer and Boyes, LLC
+1.845.623.1830*

Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)



Copyright

- *This document may be viewed and printed for personal use only.*
- *No part of this document may be copied, reproduced, transmitted, or disseminated in any electronic or non-electronic format without written permission.*
- *All rights are reserved.*

Copperhill and Pointer, Inc.

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

2



Disclaimer

- *The information presented in this document is for the general education of the reader. Because neither the author nor the publisher have control over the use of the information by the reader, both the author and publisher disclaim any and all liability of any kind arising out of such use. The reader is expected to exercise sound professional judgment in using any of the information presented in a particular application.*

*Spitzer and Boyes, LLC
Copperhill and Pointer, Inc.
Seminar Presenter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

3



Disclaimer

- *The full and complete contents of this document are for general information or use purposes only. The contents are provided "as is" without warranties of any kind, either expressed or implied, as to the quality, accuracy, timeliness, completeness, or fitness for a general, intended or particular purpose. No warranty or guaranty is made as to the results that may be obtained from the use of this document. The contents of this document are "works in progress" that will be revised from time to time.*

*Spitzer and Boyes, LLC
Copperhill and Pointer, Inc.
Seminar Presenter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

4



Disclaimer

- *Spitzer and Boyes, LLC and Copperhill and Pointer, Inc. have no liability whatsoever for consequences of any actions resulting from or based upon information in and findings of this document. In no event, including negligence, will Spitzer and Boyes, LLC or Copperhill and Pointer, Inc. be liable for any damages whatsoever, including, without limitation, incidental, consequential, or indirect damages, or loss of business profits, arising in contract, tort or other theory from any use or inability to use this document.*

*Spitzer and Boyes, LLC
Copperhill and Pointer, Inc.
Seminar Presenter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

5



Disclaimer

- *The user of this document agrees to defend, indemnify, and hold harmless Spitzer and Boyes, LLC and Copperhill and Pointer, Inc., its employees, contractors, officers, directors and agents against all liabilities, claims and expenses, including attorney's fees, that arise from the use of this document.*

*Spitzer and Boyes, LLC
Copperhill and Pointer, Inc.
Seminar Presenter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

6



Disclaimer

- *The content of this seminar was developed in an impartial manner from information provided by suppliers*
- *Discrepancies noted and brought to the attention of the editors will be corrected*
- *We do not endorse, favor, or disfavor any particular supplier or their equipment*

*Spitzer and Boyes, LLC
Copperhill and Pointer, Inc.
Seminar Presenter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

7

Seminar Outline

- **Introduction**
- *Fluid Flow Fundamentals*
- *Flowmeter Technology*
- *Flowmeter Performance*
- *Consumer Guide*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

8

Introduction

- *Working Definition of a Process*
- *Why Measure Flow?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


9

Working Definition of a Process

- *A process is anything that changes*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

10




Why Measure Flow?

- *Flow measurements provide information about the process*
- *The information that is needed depends on the process*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

11




Why Measure Flow?

- *Custody transfer*
 - *Measurements are often required to determine the total quantity of fluid that passed through the flowmeter for billing purposes*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

12




Why Measure Flow?

- *Monitor the process*
 - *Flow measurements can be used to ensure that the process is operating satisfactorily*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

13




Why Measure Flow?

- *Improve the process*
 - *Flow measurements can be used for heat and material balance calculations that can be used to improve the process*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

14




Why Measure Flow?

- *Monitor a safety parameter*
 - *Flow measurements can be used to ensure that critical portions of the process operate safely*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

15



Seminar Outline

- *Introduction*
- ***Fluid Flow Fundamentals***
- *Flowmeter Technology*
- *Flowmeter Performance*
- *Consumer Guide*



Fluid Flow Fundamentals

- ***Temperature***
- *Pressure*
- *Density and Fluid Expansion*
- *Types of Flow*
- *Inside Pipe Diameter*
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*



Temperature


- *Measure of relative hotness/coldness*
 - *Water freezes at 0°C (32°F)*
 - *Water boils at 100°C (212°F)*



Temperature

- *Removing heat from fluid lowers temperature*
 - *If all heat is removed, absolute zero temperature is reached at approximately -273°C (-460°F)*

19




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Temperature

- *Absolute temperature scales are relative to absolute zero temperature*
 - *Absolute zero temperature = 0 K (0°R)*
 - *Kelvin = $^{\circ}\text{C} + 273$*
 - *Rankin = $^{\circ}\text{F} + 460$*

20




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Temperature

- *Absolute temperature is important for flow measurement*

21



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Temperature

373 K = 100°C

273 K = 0°C


0 K = -273°C

672°R = 212°F

460°R = 0°F

0°R = -460°F

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)




Temperature

Problem

- *The temperature of a process increases from 20°C to 60°C. For the purposes of flow measurement, by what percentage has the temperature increased?*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)



Temperature

- *It is tempting to answer that the temperature tripled (60/20), but the ratio of the absolute temperatures is important for flow measurement*
 - $(60+273)/(20+273) = 1.137$
 - 13.7% increase

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)



Fluid Flow Fundamentals

- *Temperature*
- **Pressure**
- *Density and Fluid Expansion*
- *Types of Flow*
- *Inside Pipe Diameter*
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

25



Pressure

- *Pressure is defined as the ratio of a force divided by the area over which it is exerted ($P=F/A$)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

26



Pressure

Problem

- *What is the pressure exerted on a table by a 2 inch cube weighing 5 pounds?*
 - $(5 \text{ lb}) / (4 \text{ inch}^2) = 1.25 \text{ lb/in}^2$
 - *If the cube were balanced on a 0.1 inch diameter rod, the pressure on the table would be 636 lb/in²*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

27



Pressure

- *Atmospheric pressure is caused by the force exerted by the atmosphere on the surface of the earth*
 - *2.31 feet WC / psi*
 - *10.2 meters WC / bar*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

28



Pressure

- *Removing gas from a container lowers the pressure in the container*
 - *If all gas is removed, absolute zero pressure (full vacuum) is reached at approximately -1.01325 bar (-14.696 psig)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

29



Pressure

- *Absolute pressure scales are relative to absolute zero pressure*
 - *Absolute zero pressure*
 - *Full vacuum = 0 bar abs (0 psia)*
 - *bar abs = bar + 1.01325*
 - *psia = psig + 14.696*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

30



Pressure

The diagram illustrates the relationship between different pressure measurement scales. A horizontal dashed line represents the 'Atmosphere' level. Below it, a solid line represents 'Absolute Zero'. An upward arrow from 'Absolute Zero' to the 'Atmosphere' line is labeled 'Vacuum'. Another upward arrow from 'Absolute Zero' to a higher point is labeled 'Absolute'. An upward arrow from the 'Atmosphere' line to the same higher point is labeled 'Gauge'. A double-headed vertical arrow between the 'Atmosphere' line and the higher point is labeled 'Differential'.

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

31

Pressure

- *Absolute pressure is important for flow measurement*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

32

Pressure

Problem

- *The pressure of a process increases from 1 bar to 3 bar. For the purposes of flow measurement, by what percentage has the pressure increased?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

33

Pressure

- *It is tempting to answer that the pressure tripled (3/1), but the ratio of the absolute pressures is important for flow measurement*
 - $(3+1.01325)/(1+1.01325) = 1.993$
 - 99.3% increase

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

34



Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- ***Density and Fluid Expansion***
- *Types of Flow*
- *Inside Pipe Diameter*
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

35



Density and Fluid Expansion

- *Density is defined as the ratio of the mass of a fluid divided its volume*
($\rho = m/V$)

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

36



Density and Fluid Expansion

- *Specific Gravity of a liquid is the ratio of its operating density to that of water at standard conditions*
 - $SG = \rho_{\text{liquid}} / \rho_{\text{water at standard conditions}}$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

37



Density and Fluid Expansion

Problem

- *What is the density of air in a 3.2 ft³ filled cylinder that has a weight of 28.2 and 32.4 pounds before and after filling respectively?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

38



Density and Fluid Expansion

- *The weight of the air in the empty cylinder is taken into account*
 - $Mass = (32.4 - 28.2) + (3.2 \cdot 0.075)$
 $= 4.44 \text{ lb}$
 - $Volume = 3.2 \text{ ft}^3$
 - $Density = 4.44 / 3.2 = 1.39 \text{ lb/ft}^3$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

39



Density and Fluid Expansion

- *The density of most liquids is nearly unaffected by pressure*
- *Expansion of liquids*
 - $V = V_0 (1 + \beta \cdot \Delta T)$
 - V = new volume
 - V_0 = old volume
 - β = cubical coefficient of expansion
 - ΔT = temperature change

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

40



Density and Fluid Expansion

Problem

- *What is the change in density of a liquid caused by a 10°C temperature rise where β is 0.0009 per °C ?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

41



Density and Fluid Expansion

- *Calculate the new volume*
 - $V = V_0 (1 + 0.0009 \cdot 10) = 1.009 V_0$
 - *The volume of the liquid increased to 1.009 times the old volume, so the new density is (1/1.009) or 0.991 times the old density*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

42



Density and Fluid Expansion

- Expansion of solids
 - $V = V_0 (1 + \beta \cdot \Delta T)$
 - where $\beta = 3 \cdot \alpha$
 - α = linear coefficient of expansion
- Temperature coefficient
 - Stainless steel temperature coefficient is approximately 0.5% per 100°C

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

43



Density and Fluid Expansion

Problem

- What is the increase in size of metal caused by a 50°C temperature rise where the metal has a temperature coefficient of 0.5% per 100°C?

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

44



Density and Fluid Expansion

- Calculate the change in size
 - $(0.5 \cdot 50) = 0.25\%$
 - Metals (such as stainless steel) can exhibit significant expansion

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

45



Density and Fluid Expansion

- *Boyle's Law states the the volume of an ideal gas at constant temperature varies inversely with absolute pressure*
 - $V = K / P$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

46



Density and Fluid Expansion

- *New volume can be calculated*
 - $V = K / P$
 - $V_0 = K / P_0$
- *Dividing one equation by the other yields*
 - $V/V_0 = P_0 / P$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

47



Density and Fluid Expansion

Problem

- *How is the volume of an ideal gas at constant temperature and a pressure of 28 psig affected by a 5 psig pressure increase?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

48



Density and Fluid Expansion

- *Calculate the new volume*

- $V/V_0 = (28+14.7) / (28+5+14.7) = 0.895$

- $V = 0.895 V_0$

- *Volume decreased by 10.5%*

Density and Fluid Expansion

- *Charles' Law states the the volume of an ideal gas at constant pressure varies directly with absolute temperature*

- $V = K \cdot T$

Density and Fluid Expansion

- *New volume can be calculated*

- $V = K \cdot T$

- $V_0 = K \cdot T_0$

- *Dividing one equation by the other yields*

- $V/V_0 = T/T_0$

Density and Fluid Expansion

Problem

- *How is the volume of an ideal gas at constant pressure and a temperature of 15°C affected by a 10°C decrease in temperature?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

52



Density and Fluid Expansion

- *Calculate the new volume*
 - $V/V_0 = (273+15-10) / (273+15) = 0.965$
 - $V = 0.965 V_0$
 - *Volume decreased by 3.5%*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

53



Density and Fluid Expansion

- *Ideal Gas Law combines Boyle's and Charles' Laws*
 - $PV = nRT$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

54



Density and Fluid Expansion

- *New volume can be calculated*
 - $P \cdot V = n \cdot R \cdot T$
 - $P_0 \cdot V_0 = n \cdot R \cdot T_0$
- *Dividing one equation by the other yields*
 - $V/V_0 = (P_0/P) \cdot (T/T_0)$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

55



Density and Fluid Expansion

Problem

- *How is the volume of an ideal gas at affected by a 10.5% decrease in volume due to temperature and a 3.5% decrease in volume due to pressure?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

56



Density and Fluid Expansion

- *Calculate the new volume*
 - $V/V_0 = 0.895 \cdot 0.965 = 0.864$
 - $V = 0.864 V_0$
 - *Volume decreased by 13.6%*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

57



Density and Fluid Expansion

- *Non-Ideal Gas Law takes into account non-ideal behavior*
 - $PV = nRTZ$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

58



Density and Fluid Expansion

- *New volume can be calculated*
 - $P \cdot V = n \cdot R \cdot T \cdot Z$
 - $P_0 \cdot V_0 = n \cdot R \cdot T_0 \cdot Z_0$
- *Dividing one equation by the other yields*
 - $V/V_0 = (P_0/P) \cdot (T/T_0) \cdot (Z/Z_0)$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

59



Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- *Density and Fluid Expansion*
- **Types of Flow**
- *Inside Pipe Diameter*
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

60



Types of Flow

- $Q = A \cdot v$
 - Q is the volumetric flow rate
 - A is the cross-sectional area of the pipe
 - v is the average velocity of the fluid in the pipe

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

61



Types of Flow

- Typical Volumetric Flow Units ($Q = A \cdot v$)
 - $\text{ft}^2 \cdot \text{ft}/\text{sec} = \text{ft}^3/\text{sec}$
 - $\text{m}^2 \cdot \text{m}/\text{sec} = \text{m}^3/\text{sec}$
 - gallons per minute (gpm)
 - liters per minute (lpm)
 - cubic centimeters per minute (ccm)

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

62



Types of Flow

- $W = \rho \cdot Q$
 - W is the mass flow rate
 - ρ is the fluid density
 - Q is the volumetric flow rate

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

63



Types of Flow

- *Typical Mass Flow Units ($W = \rho \cdot Q$)*
 - $\text{lb/ft}^3 \cdot \text{ft}^3/\text{sec} = \text{lb/sec}$
 - $\text{kg/m}^3 \cdot \text{m}^3/\text{sec} = \text{kg/sec}$
 - *standard cubic feet per minute (scfm)*
 - *standard liters per minute (slpm)*
 - *standard cubic centimeters per minute (sccm)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

64



Types of Flow

- $Q = A \cdot v$
- $W = \rho \cdot Q$
 - Q *volumetric flow rate*
 - W *mass flow rate*
 - v *fluid velocity*
 - $\frac{1}{2} \rho v^2$ *inferential flow rate*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

65



Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- *Density and Fluid Expansion*
- *Types of Flow*
- ***Inside Pipe Diameter***
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

66




Inside Pipe Diameter

- *The **inside pipe diameter (ID)** is important for flow measurement*
 - *Pipes of the same size have the same outside diameter (OD)*
 - *Welding considerations*
 - *Pipe wall thickness, and hence its ID, is determined by its schedule*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

67




Inside Pipe Diameter

- *Pipe wall thickness increases with increasing pipe schedule*
 - *Schedule 40 pipes are considered “standard” wall thickness*
 - *Schedule 5 pipes have thin walls*
 - *Schedule 160 pipes have thick walls*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

68




Inside Pipe Diameter

- *Nominal pipe size*
 - *For pipe sizes 12-inch and smaller, the nominal pipe size is the approximate ID of a Schedule 40 pipe*
 - *For pipe sizes 14-inch and larger, the nominal pipe size is the OD of the pipe*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

69



Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- *Density and Fluid Expansion*
- *Types of Flow*
- *Inside Pipe Diameter*
- **Viscosity**
- *Reynolds Number and Velocity Profile*
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

70



Viscosity

- *Viscosity is the ability of the fluid to flow over itself*
- *Units*
 - *cP, cSt*
 - *Saybolt Universal (at 100°F, 210 °F)*
 - *Saybolt Furol (at 122°F, 210 °F)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

71



Viscosity

- *Viscosity can be highly temperature dependent*
 - *Water*
 - *Honey at 40°F, 80°F, and 120°F*
 - *Peanut butter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

72



Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- *Density and Fluid Expansion*
- *Types of Flow*
- *Inside Pipe Diameter*
- *Viscosity*
- ***Reynolds Number and Velocity Profile***
- *Hydraulic Phenomena*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

73



Velocity Profile and Reynolds Number

- *Reynolds number is the ratio of inertial forces to viscous forces in the flowing stream*
- $R_D = 3160 \cdot Q_{gpm} \cdot SG / (\mu_{cP} \cdot D_{in})$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

74



Velocity Profile and Reynolds Number

- *Reynolds number can be used as an indication of how the fluid is flowing in the pipe*
- *Flow regimes based on R_D*
 - *Laminar* < 2000
 - *Transitional* 2000 - 4000
 - *Turbulent* > 4000

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

75




Velocity Profile and Reynolds Number

- *Not all molecules in the pipe flow at the same velocity*
- *Molecules near the pipe wall move slower; molecules in the center of the pipe move faster*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

76




Velocity Profile and Reynolds Number

- *Laminar Flow Regime*
 - *Molecules move straight down pipe*




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

77




Velocity Profile and Reynolds Number

- *Turbulent Flow Regime*
 - *Molecules migrate throughout pipe*




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

78



Velocity Profile and Reynolds Number

- *Transitional Flow Regime*
 - *Molecules exhibit both laminar and turbulent behavior*




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

79

Velocity Profile and Reynolds Number

- *Many flowmeters require a good velocity profile to operate accurately*
- *Obstructions in the piping system can distort the velocity profile*
 - *Elbows, tees, fittings, valves*




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

80

Velocity Profile and Reynolds Number

- *A distorted velocity profile can introduce significant errors into the measurement of most flowmeters*



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


81

Velocity Profile and Reynolds Number

- *Good velocity profiles can be developed*
 - *Straight run upstream and downstream*
 - *No fittings or valves*
 - *Upstream is usually longer and more important*
 - *Flow conditioner*
 - *Locate control valve downstream of flowmeter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

82




Fluid Flow Fundamentals

- *Temperature*
- *Pressure*
- *Density and Fluid Expansion*
- *Types of Flow*
- *Inside Pipe Diameter*
- *Viscosity*
- *Reynolds Number and Velocity Profile*
- ***Hydraulic Phenomena***

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

83




Hydraulic Phenomena

- *Vapor pressure is defined as the pressure at which a liquid and its vapor can exist in equilibrium*
 - *The vapor pressure of water at 100°C is atmospheric pressure (1.01325 bar abs) because water and steam can coexist*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

84



Hydraulic Phenomena

- *A saturated vapor is in equilibrium with its liquid at its vapor pressure*
 - *Saturated steam at atmospheric pressure is at a temperature of 100°C*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

85



Hydraulic Phenomena

- *A superheated vapor is a saturated vapor that is at a higher temperature than its saturation temperature*
 - *Steam at atmospheric pressure that is at 150°C is a superheated vapor with 50°C of superheat*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

86



Hydraulic Phenomena

- *Flashing is the formation of gas (bubbles) in a liquid after the pressure of the liquid falls below its vapor pressure*
 - *Reducing the pressure of water at 100°C below atmospheric pressure (say 0.7 bar abs) will cause the water to boil*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

87



Hydraulic Phenomena


- *Cavitation is the formation and subsequent collapse of gas (bubbles) in a liquid after the pressure of the liquid falls below and then rises above its vapor pressure*
 - *Can cause severe damage in pumps and valves*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

88



Hydraulic Phenomena



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

89



Hydraulic Phenomena

- *Energy Considerations*
 - *Claims are sometimes made that flowmeters with a lower pressure drop will save energy*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

90



Hydraulic Phenomena

- *Energy Considerations*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

91

Hydraulic Phenomena

- *Energy Considerations*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

92

Hydraulic Phenomena


- *Energy Considerations*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

93

Hydraulic Phenomena

Energy Considerations




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

94

Hydraulic Phenomena

Energy Considerations



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

95


Hydraulic Phenomena

Energy Considerations

- *The pump operates at the same flow and pressure, so no energy savings are achieved by installing a flowmeter with a lower pressure drop*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

96



- ## Hydraulic Phenomena
- *Energy Considerations*
- *Operating the pump at a reduced speed generates the same flow but requires a lower pump discharge pressure*
 - *Hydraulic energy generated by the pump better matches the load*
 - *Energy savings are proportional to the cube of the speed*
- Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)
- 98

- ## Seminar Outline
- *Introduction*
 - *Fluid Flow Fundamentals*
 - ***Flowmeter Technology***
 - *Flowmeter Performance*
 - *Consumer Guide*
- Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)
- 99

Coriolis Mass Flowmeter Technology

- **Principle of Operation**
- *Tube Geometry*
- *Flowmeter Designs*
- *Transmitter Designs*
- *Installation*
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

100



Principle of Operation

- *Coriolis mass flowmeters use the properties of mass to measure mass*
 - *Thermal mass flowmeters assume constant thermal properties*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

101




Principle of Operation

- *Coriolis acceleration*



Man Standing Still



Man Moving Outward

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

102




Principle of Operation

- *Man Standing Still*
 - *Velocity in tangential plane is constant*

$$\begin{aligned}
 F_{tang} &= m \cdot a_{tang} \\
 &= m \cdot \Delta v_{tang} / \Delta t \\
 &= m \cdot (r \cdot \omega - r \cdot \omega) / \Delta t \\
 &= m \cdot 0 / \Delta t \\
 &= 0 \text{ (no force in tangential plane)}
 \end{aligned}$$

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)




Principle of Operation

- *Man Moving Outward*
 - *Velocity in tangential plane changes*

$$\begin{aligned}
 F_{tang} &= m \cdot a_{tang} \\
 &= m \cdot \Delta v_{tang} / \Delta t \\
 &= m \cdot ((r + \Delta r) \cdot \omega - r \cdot \omega) / \Delta t \\
 &= m \cdot \Delta r \cdot \omega / \Delta t \\
 &\neq 0 \text{ (force in tangential plane)}
 \end{aligned}$$


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)



Principle of Operation

- *Components that produce Coriolis force*
 - *Rotation*
 - *Motion towards/away from center of rotation*
 - *Resultant Coriolis acceleration*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)




Principle of Operation

- *U-tube Coriolis mass flowmeter*
 - *Rotation*
 - *Oscillation about a plane parallel to the centerline of the piping connections*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

106




Principle of Operation

- *U-tube Coriolis mass flowmeter*
 - *Motion towards/away from center of rotation*
 - *Mass flow through U-tube towards/away from the centerline of piping connections*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

107




Principle of Operation


- *U-tube Coriolis mass flowmeter*
 - *Coriolis force*
 - *Twist of U-tube*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

108



Coriolis Mass Flowmeter



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

109

Principle of Operation

Experiment

- Hold a garden hose with both hands so it sags near the floor (like a U-tube)
- Turning water on/off has little affect on the position of the hose

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

110

Principle of Operation

Experiment

- Swing the hose toward and away from your body
- Turning on the water will cause the sides of the U-tube to move towards/away from you
- Stopping the swinging will stop the movement and relax the U-tube

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


111

Principle of Operation

- *Coriolis acceleration is proportional to the mass flow*
- *Coriolis acceleration generates a force*
- *Coriolis force twists the U-tube*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

112




Principle of Operation

- *Mass flow is proportional to the Coriolis force that twists the U-tube*
 - *Measure the twist of the U-tube*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

113




Principle of Operation

- *Amount of twist depends on mechanical properties of the U-tube*
 - *Material*
 - *Wall thickness*
 - *Temperature*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

114




Principle of Operation

- *Temperature Measurement*
 - *Pipe wall temperature is measured to compensate for material properties*
 - *Many Coriolis mass flowmeters offer (an optional) temperature measurement output*
 - *Not process temperature*
 - *Outside pipe wall temperature*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

115




Principle of Operation

- *Density Measurement*
 - *The frequency of oscillation is related to fluid density*
 - *Many Coriolis mass flowmeters offer (an optional) density measurement output*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

116




Principle of Operation

- *Viscosity Measurement*
 - *In the laminar flow regime, the mass flow measurement, temperature measurement, and external differential pressure measurement across the flowmeter is used to calculate viscosity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

117



Principle of Operation

- *Viscosity Measurement*
 - *To counteract the effects of pipe vibration, one Coriolis mass flowmeter uses a weight that twists the tube*
 - *Measurement of the forces due this twist are used to determine the fluid viscosity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

118


Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- **Tube Geometry**
- *Flowmeter Designs*
- *Transmitter Designs*
- *Installation*
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

119

Tube Geometry – Single U-tube



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

120


Tube Geometry – Single U-tube

- *First practical design*
- *Sensors connected to case*
 - *Measure movement relative to case*
 - *Susceptible to pipe vibration*
- *Rigid support structures*
 - *Metal plate*
 - *Concrete foundation*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

121

Tube Geometry – Dual U-tube



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

122


Tube Geometry – Dual U-tube

- *Flow split between two tubes*
- *Sensors connected to case*
 - *Measure relative movement of tubes*
 - *Reduced susceptibility to pipe vibration*
- *Mount flowmeter in piping*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

123

Tube Geometry – B-Tube




B-tube Design
Foxboro

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

124

Tube Geometry – Curved Tube




Curved Tube Design
Endress+Hauser, Micromotion, Oval

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

125

Tube Geometry – Curved Tube




Curved Tube Design
ABB

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

126

Tube Geometry – Delta




Delta Tube Design
Micromotion

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

127

Tube Geometry – Diamond




Diamond Tube Design
Kueppers

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

128

Tube Geometry – Omega




Omega Tube Design
Actaris (Schlumberger)

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

129

Tube Geometry – Omega




Omega Tube Design
Heinrichs

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

130

Tube Geometry – Round




Round Tube Design
Rheonik

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

131

Tube Geometry – Straight




Straight Dual Tube Design
Endress+Hauser

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

132

Tube Geometry – Straight




Straight Single Tube Design

Brooks, Endress+Hauser, Krohne, Micromotion, Oval

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

133

Tube Geometry – S-Tube




S-Tube Design

FMC Energy Systems

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

134

Tube Geometry – S-Tube




S-Tube Design

FMC Energy Systems

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

135

Tube Geometry – S-Tube




S-Tube Design
Krohne

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

136

Tube Geometry– U-Tube




Single U-Tube Design
Brooks, Micromotion

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

137

Tube Geometry– U-Tube




Dual U-Tube Design
Micromotion, Oval, Yokogawa

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

138

Tube Geometry – U-Tube



U-Tube Design

Danfoss

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

139

Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- *Tube Geometry*
- ***Flowmeter Designs***
- *Transmitter Designs*
- *Installation*
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

140

Coriolis Mass Flowmeter Designs

- *Liquid*
- *Gas*
- *High Pressure*
- *High Temperature*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

141

Coriolis Mass Flowmeter Designs

- *Metal (other than stainless steel)*
- *Plastic/Polymer*
- *Sanitary*
- *Single Path*
- *Straight Path*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

142



Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- *Tube Geometry*
- *Flowmeter Designs*
- ***Transmitter Designs***
- *Installation*
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

143



Coriolis Mass Flowmeter Transmitter Designs

- *Analog*
 - *Electrical components subject to drift*
 - *Mathematical corrections difficult*
 - *Four-wire design*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

144



Coriolis Mass Flowmeter Transmitter Designs

- *Digital*
 - *Microprocessor is less susceptible to drift*
 - *Mathematical corrections in software*
 - *Four-wire design*
 - *Remote communication (with HART)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

145



Coriolis Mass Flowmeter Transmitter Designs

- *Digital*
 - *Typical design measures a parameter related to flow*
 - *Some designs digitize raw signals that are processed digitally*
 - *One design measures two-phase flow by controlling tube vibration and proprietary signal processing algorithms*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

146



Coriolis Mass Flowmeter Transmitter Designs

- *Fieldbus*
 - *Microprocessor is less susceptible to drift*
 - *Mathematical corrections in software*
 - *Multi-drop wiring*
 - *Remote communication*
 - *Issues with multiple protocols*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

147



Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- *Tube Geometry*
- *Flowmeter Designs*
- *Transmitter Designs*
- **Installation**
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

148



Installation

- *Fluid Characteristics*
- *Piping and Hydraulics*
- *Mounting*
- *Electrical*
- *Ambient Conditions*
- *Setup Information*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

149



Fluid Characteristics

- *Single-phase homogeneous*
 - *Liquid*
 - *Gas*
 - *Vapor*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

150




Fluid Characteristics

- *Two-phase*
 - *Liquid/solid*
 - *Liquid/gas*
- *Avoid flashing*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

151




Fluid Characteristics

- *Within accurate flow range*
- *Corrosion and erosion*
- *Immiscible fluids*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

152




Piping and Hydraulics

- *For liquid applications, keep the flowmeter full of liquid*
 - *Hydraulic design*
 - *Vertical riser preferred*
 - *Avoid inverted U-tube*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

153




Piping and Hydraulics

- *For liquid applications, orient to self-fill and self-drain*
 - *Self-filling is important to ensure a full pipe*
 - *If not, special precautions must be taken when zeroing the flowmeter*
 - *If not, gas/vapor can accumulate, especially at low flow conditions*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

154




Piping and Hydraulics

- *For liquid applications, keep the flowmeter full of liquid*
 - *Hydraulic design*
 - *Be careful when flowing downwards*
 - *Be careful when flowing by gravity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

155




Piping and Hydraulics

- *For gas/vapor applications, keep the flowmeter full of gas/vapor*
 - *Hydraulic design*
 - *Self-draining*
 - *Vertical preferred*
 - *Avoid U-tube*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

156



Piping and Hydraulics

- *For gas/vapor applications, calculate pressure drop carefully*
 - *Mass flow range of a given size flowmeter is fixed*
 - *Relatively small mass occupies a relatively large volume*
 - *High velocity and high pressure drop result*
 - *Flowmeter will operate low in its range*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

157



Piping and Hydraulics

- *Wetted parts compatible with fluid*
- *Sanitary applications*
 - *Orient to self-fill and self-drain*
 - *Compatible with cleaning solutions*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

158



Piping and Hydraulics

- *Maintain good velocity profile*
 - *Locate control valve downstream of flowmeter*
 - *Provide adequate straight run*
 - *Locate most straight run upstream*
 - *Use full face gaskets*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

159



Piping and Hydraulics

- *Install a positive shut-off valve downstream of the flowmeter to zero the flowmeter at process temperature and process pressure*
 - *Some suppliers have specific instructions regarding gas removal when installation is not self-filling (liquid)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

160



Piping and Hydraulics

- *When locating two or more Coriolis mass flowmeters near each other, it is possible for their vibrations to interact*
 - *Different vibration frequencies*
 - *Isolate with supports and flexible connections*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

161



Mounting

- *Mount the flowmeter between flanges that are parallel, axially aligned, and proper spacing*
- *Locate the flowmeter so as to reduce vibration*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

162



Mounting

- *Some suppliers recommend:*
 - *mounting on a solid base plate*
 - *mounting heavy sensors on a rigid support*
 - *upstream bends not in certain planes that could dampen oscillations*
 - *symmetric supports up/downstream*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

163



Electrical

- *Integral sensors reduce wiring cost*
- *Wiring*
 - *Low voltage power supply can eliminate power conduit*
 - *Fieldbus reduces wiring*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

164



Ambient Conditions

- *Outdoor applications (-20 to 60°C)*
 - *Some designs are for indoor locations*
- *Hazardous locations*
 - *Some designs are general purpose*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

165




Setup Information

- *GIGO (garbage in – garbage out)*
- *Entering correct information correctly is critical*
 - *Dimensions*
 - *Materials of construction*
 - *Fluid properties*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

166




Setup Information

- *Failure to use correct information can cause significant error and startup problems*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

167




Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- *Tube Geometry*
- *Flowmeter Designs*
- *Transmitter Designs*
- *Installation*
- *Accessories*
- *Other Flowmeter Technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

168



Accessories

- *Flow Tube*
 - *NEMA 4X and IP67 (IP68)*
 - *High pressure*
 - *High temperature*
 - *Non-316SS*
 - *Sanitary*
 - *Secondary containment*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

169



Accessories

- *Flow Tube*
 - *Purge fittings*
 - *Heating jacket*
 - *Removable insulation*
 - *Rupture disk*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

170




Accessories

- *Transmitter*
 - *NEMA 4X and IP67*
 - *Senor wiring is often intrinsically safe*
 - *Analog output*
 - *Pulse output*
 - *Totalization and alarms*
 - *HART, Foundation Fieldbus, Profibus*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

171



Coriolis Mass Flowmeter Technology

- *Principle of Operation*
- *Tube Geometry*
- *Flowmeter Designs*
- *Transmitter Designs*
- *Installation*
- *Accessories*
- ***Other Flowmeter Technologies***

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

172



Other Flowmeter Technologies

- *Coriolis Mass* *Insertion*
- *Differential Pressure*
- *Magnetic*
- *Positive Displacement*
- *Target*
- *Thermal*
- *Turbine*
- *Ultrasonic*
- *Vortex Shedding*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

173



Coriolis Mass Flowmeter


- *Coriolis mass flowmeters measure the force generated as the fluid moves towards/away from its center of rotation*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

174



Coriolis Mass Flowmeter



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

175


Differential Pressure Flowmeter

- *A piping restriction is used to develop a pressure drop that is measured and used to infer fluid flow*
 - *Primary Flow Element*
 - *Transmitter (differential pressure)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

176


Orifice Plate Primary Flow Element



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

177

Venturi Primary Flow Element




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

178



Flow Nozzle Primary Flow Element




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

179



V-Cone™ Primary Flow Element



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

180



Differential Pressure Flowmeter

- *Pressure drop is proportional to the square of the fluid flow rate*
 - $\Delta p \propto Q^2$ or $Q \propto \sqrt{\Delta p}$
 - *Double the flow... four times the differential*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

181

Differential Pressure Flowmeter

- *Low flow measurement can be difficult*
 - *For example, only 1/4 of the differential pressure is generated at 50 percent of the full scale flow rate. At 10 percent flow, the signal is only 1 percent of the differential pressure at full scale.*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

182

Magnetic Flowmeter

- *Fluid flow through a magnetic field generates a voltage at the electrodes that is proportional to fluid velocity*
 - *Primary Flow Element*
 - *Transmitter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

183

Magnetic Flowmeter

Magnet
 Tube (non-magnetic)
 Liner (insulating)
 Flow →
 Electrode

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

184

Magnetic Flowmeter

- *Traditional AC excitation was susceptible to noise and drift*
 - *A low voltage signal is generated that is susceptible to noise and cross-talk at the excitation frequency*

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

185

Magnetic Flowmeter

- *Pulsed DC excitation reduces drift by turning the magnet on and off*
 - *Noise (while the magnet is off) is subtracted from signal and noise (while the magnet is on) to reduce the effects of noise and cross-talk*
 - *Response time can be compromised*

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

186

Positive Displacement Flowmeter

- *Positive displacement flowmeters measure flow by repeatedly entrapping fluid within the flowmeter*
 - *Moving parts with tight tolerances*
 - *Bearings*
 - *Many shapes*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

187



Target Flowmeter


- *Target flowmeters determine flow by measuring the force exerted on a body (target) suspended in the flow stream*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

188



Target Flowmeter



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


189



Thermal Flowmeter

- *Thermal flowmeters use the thermal properties of the fluid to measure flow*
 - *Hot Wire Anemometer*
 - *Thermal Profile*


190




Thermal Flowmeter Hot Wire Anemometer

- *Hot wire anemometers determine flow by measuring the amount of energy needed to heat a probe whose heat loss changes with flow rate*


191



Thermal Flowmeter Hot Wire Anemometer



192




Thermal Flowmeter Thermal Profile


- *Thermal profile flowmeters determine flow by measuring the temperature difference that results in a heated tube when the fluid transfers heat from the upstream portion to the downstream portion of the flowmeter*

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

193



Thermal Flowmeter Thermal Profile



Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


194

Turbine Flowmeter

- *Fluid flow causes a rotor to spin whereby the rotor speed is proportional to fluid velocity*
 - *Primary Flow Element*
 - *Transmitter*

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

195



Turbine Flowmeter

Flow →

Sensor/Transmitter

Rotor

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

196

Turbine Flowmeter

- *The sensor detects the rotor blades*
- *The frequency of the rotor blades passing the sensor is proportional to fluid velocity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

197

Ultrasonic - Doppler

- *Doppler ultrasonic flowmeters reflect ultrasonic energy from particles, bubbles and/or eddies flowing in the fluid*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

198

Ultrasonic - Doppler

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)
199

Ultrasonic - Doppler

- *Under no flow conditions, the frequencies of the ultrasonic beam and its reflection are the same*
- *With flow in the pipe, the difference between the frequency of the beam and its reflection increases proportional to fluid velocity*


Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)
200

Ultrasonic - Transit Time

- *Transit time (time-of-flight) ultrasonic flowmeters alternately transmit ultrasonic energy into the fluid in the direction and against the direction of flow*

Spitzer and Boyes, LLC (+1.845.623.1830)
 Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)
201

Ultrasonic - Transit Time



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

202

Ultrasonic - Transit Time


- *The time difference between ultrasonic energy moving upstream and downstream in the fluid is used to determine fluid velocity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

203

Ultrasonic - Transit Time

- *Under no flow conditions, the time for the ultrasonic energy to travel upstream and downstream are the same*




Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

204

Ultrasonic - Transit Time

- *With flow in the pipe, the time for the ultrasonic energy to travel upstream will be greater than the downstream time*



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

205


Vortex Shedding Flowmeter

- *A bluff body in the flow stream creates vortices whereby the number of vortices is proportional to the fluid velocity*
 - *Primary Flow Element*
 - *Transmitter*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

206

Vortex Shedding Flowmeter



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

207

Vortex Shedding Flowmeter

- *The sensing system detects the vortices created*
- *The frequency of the vortices passing the sensing system is proportional to fluid velocity*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

208



Insertion Flowmeter


- *Insertion flowmeter infer the flow in the entire pipe by measuring flow at one or more strategic locations in the pipe*
 - *Differential Pressure*
 - *Magnetic*
 - *Target*
 - *Thermal*
 - *Turbine*
 - *Vortex*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

209



Insertion Flowmeter



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

210



Seminar Outline

- *Introduction*
- *Fluid Flow Fundamentals*
- *Flowmeter Technology*
- ***Flowmeter Performance***
- *Consumer Guide*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

211



Flowmeter Performance

- ***Flowmeter Performance***
- *Performance Statements*
- *Reference Performance*
- *Pulse Output vs. Analog Output*
- *Actual Performance*
- *Supplier Claims*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

212



Flowmeter Performance

- *Accuracy is the ability of the flowmeter to produce a measurement that corresponds to its characteristic curve*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

213



Flowmeter Performance

Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Flowmeter Performance

- *Repeatability is the ability of the flowmeter to reproduce a measurement each time a set of conditions is repeated*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Flowmeter Performance


Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Flowmeter Performance


- *Linearity is the ability of the relationship between flow and flowmeter output (often called the characteristic curve or signature of the flowmeter) to approximate a linear relationship*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

217



Flowmeter Performance




Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


Flowmeter Performance

- *Flowmeter suppliers often specify the composite accuracy that represents the combined effects of repeatability, linearity and accuracy*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

219





- ## Flowmeter Performance
- *Flowmeter Performance*
 - **Performance Statements**
 - *Reference Performance*
 - *Pulse Output vs. Analog Output*
 - *Actual Performance*
 - *Supplier Claims*
- Spitzer and Boyes, LLC (+1.845.623.1830) 221
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


- ## Performance Statements
- *Percent of rate*
 - *Percent of full scale*
 - *Percent of meter capacity (upper range limit)*
 - *Percent of calibrated span*
- Spitzer and Boyes, LLC (+1.845.623.1830) 222
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Performance Statements


- *1% of rate performance at different flow rates with a 0-100 unit flow range*
 - *100% flow* $\rightarrow 0.01 \cdot 100$ *1.00 unit*
 - *50% flow* $\rightarrow 0.01 \cdot 50$ *0.50 unit*
 - *25% flow* $\rightarrow 0.01 \cdot 25$ *0.25 unit*
 - *10% flow* $\rightarrow 0.01 \cdot 10$ *0.10 unit*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

223




Performance Statements



Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

224





Performance Statements

- *1% of full scale performance at different flow rates with a 0-100 unit flow range*
 - *100% flow* $\rightarrow 0.01 \cdot 100$ *1 unit = 1% rate*
 - *50% flow* $\rightarrow 0.01 \cdot 100$ *1 unit = 2% rate*
 - *25% flow* $\rightarrow 0.01 \cdot 100$ *1 unit = 4% rate*
 - *10% flow* $\rightarrow 0.01 \cdot 100$ *1 unit = 10% rate*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

225





- ### Performance Statements
- 1% of meter capacity (or upper range limit) performance at different flow rates with a 0-100 unit flow range (URL=400)
 - 100% flow $\rightarrow 0.01 \cdot 400$ 4 units = 4% rate
 - 50% flow $\rightarrow 0.01 \cdot 400$ 4 units = 8% rate
 - 25% flow $\rightarrow 0.01 \cdot 400$ 4 units = 16% rate
 - 10% flow $\rightarrow 0.01 \cdot 400$ 4 units = 40% rate
- Spitzer and Boyes, LLC (+1.845.623.1830) 227
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)



Performance Statements

- *Performance expressed as a percent of calibrated span is similar to full scale and meter capacity statements where the absolute error is a percentage of the calibrated span*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

229


Performance Statements

- *1% of calibrated span performance at different flow rates with a 0-100 unit flow range (URL=400, calibrated span=200)*
 - *100% flow $\rightarrow 0.01 \cdot 200$ 2 units = 2% rate*
 - *50% flow $\rightarrow 0.01 \cdot 200$ 2 units = 4% rate*
 - *25% flow $\rightarrow 0.01 \cdot 200$ 2 units = 8% rate*
 - *10% flow $\rightarrow 0.01 \cdot 200$ 2 units = 20% rate*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

230

Performance Statements




Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

Performance Statements

- *A calibrated span statement becomes a full scale statement when the instrument is calibrated to full scale*
- *A calibrated span statement becomes a meter capacity statement when the instrument is calibrated at URL*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

232





Performance Statements

- *Performance specified as a percent of rate, percent of full scale, percent of meter capacity, and percent of calibrated span are different*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

233






Performance Statements

- *Performance statements apply over a range of operation*
- *Turndown is the ratio of the maximum flow that the flowmeter will measure within the stated accuracy to the minimum flow that can be measured within the stated accuracy*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

235




Performance Statements

- *Performance statements can be manipulated because their meaning may not be clearly understood*
- *Technical assistance may be needed to analyze the statements*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

236




Flowmeter Performance

- *Flowmeter Performance*
- *Performance Statements*
- **Reference Performance**
- *Pulse Output vs. Analog Output*
- *Actual Performance*
- *Supplier Claims*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

237



Reference Performance

- *Reference performance is the quality of measurement at a nominal set of operating conditions, such as:*
 - *Water at 20°C in ambient conditions of 20°C and 50 percent relative humidity*
 - *Long straight run*
 - *Pulse output*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

238



Reference Performance

- *In the context of the industrial world, reference performance reflects performance under controlled laboratory conditions*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

239



Performance Statements

- *For most Coriolis mass flowmeters, performance statements are the combination of:*
 - *Percentage of rate*
 - *Zero stability*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


240



Performance Statements

- *Combination performance statement*
 - *Zero adjustment exists*
 - *Zero is is not well-defined*
 - *Zero adjustment is performed well*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 241



Reference Performance

- *Hypothetical flowmeter*
 - *0.1% rate*
 - *0.025 kg/min*
 - *Zero stability (depends on size)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 242




Reference Performance

Example - Omission

- *Hypothetical flowmeter*
 - *0.10% rate*
- *This statement could be interpreted to apply over the entire flow range*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 243



Reference Performance

Example - Omission

- Hypothetical flowmeter
 - 0.10% rate plus 0.025 kg/min
- 0.10% rate dominates at high flows
- 0.025 kg/min dominates at low flows

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

244



Reference Performance

Problem

- What is the performance of a Coriolis mass flowmeter with the following accuracy specifications?
 - 0.10% rate plus 0.025 kg/min
 - Assume a 0-100 kg/min flow range

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

245



Reference Performance

Solution

- Rate statement error
 - 100% flow $\rightarrow 0.001 \cdot 100$ 0.100 kg/min
 - 50% flow $\rightarrow 0.001 \cdot 50$ 0.050 “
 - 25% flow $\rightarrow 0.001 \cdot 25$ 0.025 “
 - 10% flow $\rightarrow 0.001 \cdot 10$ 0.010 “
 - 1% flow $\rightarrow 0.001 \cdot 1$ 0.001 “

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

246



Reference Performance

Solution

- *Flow error*
 - 100% flow $\rightarrow 0.100 + 0.025 = 0.125 \text{ kg/min}$
 - 50% flow $\rightarrow 0.050 + 0.025 = 0.075$ “
 - 25% flow $\rightarrow 0.025 + 0.025 = 0.050$ “
 - 10% flow $\rightarrow 0.010 + 0.025 = 0.035$ “
 - 1% flow $\rightarrow 0.001 + 0.025 = 0.026$ “

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

247



Reference Performance

Solution

- *Performance expressed as a percent of rate*
 - 100% flow $\rightarrow 0.125/100$ 0.13 % rate
 - 50% flow $\rightarrow 0.075/50$ 0.15 % “
 - 25% flow $\rightarrow 0.050/25$ 0.20 % “
 - 10% flow $\rightarrow 0.035/10$ 0.35 % “
 - 1% flow $\rightarrow 0.026/1$ 2.60 % “

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

248



Reference Performance

- *Performance at low flow rates is degraded as compared to the 0.10% rate statement (while still meeting specifications)*
 - Rate statement dominates at high flows
 - Zero stability dominates at low flows

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

249



Reference Performance

- *Rate statements are often discussed*
- *Zero stability issues are often only mentioned with prompting*
 - *Progressive disclosure*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

250



Reference Performance

- *Flow Laboratory Performance*
 - *Flow laboratory is used to ensure that the flowmeter performs per specifications*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

251



Reference Performance

- *Uncertainty Analysis*
 - *Formal document that quantifies flow laboratory performance*
 - *Opportunity to take a critical look at the facility*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

252




Reference Performance

- *Uncertainty Analysis*
 - *Performance degrades as the look becomes more in-depth*
 - *Buoyancy*
 - *Analog input error*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

253




Reference Performance

- *Uncertainty Analysis*
 - *Best when performed/reviewed independently*
 - *Results can suggest improvements*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

254




Reference Performance

- *Flow Laboratory Performance*
 - *The "Rule of Thumb" is that the calibration standard should be at least 4 times better than instrument*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


255



Reference Performance

- *Flow Laboratory Performance*
 - *4:1 implies uncertainty of 0.025% rate*
 - *Difficult to achieve and maintain*
 - *Shows importance of formal uncertainty analysis*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 256



Reference Performance

- *Flow Laboratory Performance*
 - *Some suppliers have not performed an uncertainty analysis, other suppliers did not know the uncertainty*
 - *Calibrations performed in these laboratories may be suspect*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 257



Flowmeter Performance

- *Flowmeter Performance*
- *Performance Statements*
- *Reference Performance*
- ***Pulse Output vs. Analog Output***
- *Actual Performance*
- *Supplier Claims*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 258



Pulse Output vs. Analog Output

- *Most suppliers specify pulse output performance*
 - *Analog output performance is typically the pulse output performance plus an absolute error*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

259

Pulse Output vs. Analog Output

Problem

- *What is the error associated with a 4-20mA analog output that has an error of 0.010 mA?*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

260

Pulse Output vs. Analog Output

Solution

- *The conversion error is:*
 - $0.010/(20-4) = 0.06\%$ of full scale
- *Some flowmeters have analog output errors of 0.10% of full scale*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

261

Pulse Output vs. Analog Output

Solution

<u>Flow</u>	<u>0.06% Full Scale</u>
100 units	$0.06 * 100 / 100 = 0.06\%$ rate
50 “	$0.06 * 100 / 50 = 0.12$ “
25 “	$0.06 * 100 / 25 = 0.24$ “
10 “	$0.06 * 100 / 10 = 0.60$ “

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

262

Pulse Output vs. Analog Output

Solution

<u>Flow</u>	<u>0.03% Full Scale</u>
100 units	$0.03 * 100 / 100 = 0.03\%$ rate
50 “	$0.03 * 100 / 50 = 0.06$ “
25 “	$0.03 * 100 / 25 = 0.12$ “
10 “	$0.03 * 100 / 10 = 0.30$ “

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

263

Pulse Output vs. Analog Output

- Some suppliers cannot provide an analog output accuracy specification, so the performance of the analog output may be **undefined**

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

264

Pulse Output vs. Analog Output

- *In some flowmeter designs, the analog output error can be **larger** than the flowmeter accuracy*
 - *Often applies to flowmeters with percent of rate accuracy*
 - *Rate error increases at low flow rates*
 - *Others often include the analog output error in their pulse accuracy statement*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

265



Pulse Output vs. Analog Output

- *Flowmeters with percent of full scale, meter capacity, and calibrated span often include the analog output error in their pulse accuracy statement*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

266



Pulse Output vs. Analog Output

Example

- *An analog output error of 0.10% of full scale is usually neglected for a flowmeter that exhibits 1% of full scale performance.*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

267




Flowmeter Performance

- *Flowmeter Performance*
- *Performance Statements*
- *Reference Performance*
- *Pulse Output vs. Analog Output*
- ***Actual Performance***
- *Supplier Claims*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

268




Actual Performance

- *Operating Effects*
 - *Ambient conditions*
 - *Humidity*
 - *Precipitation*
 - *Temperature*
 - *Direct sunlight*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

269




Actual Performance

- *Many flowmeters are rated to 10-90% relative humidity (non-condensing)*
 - *Outdoor locations are subject to 100% relative humidity and precipitation in various forms*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

270




Actual Performance

- *Operating Effects*
 - *Can be significant, even though the numbers seem small*
 - *Not published by most suppliers*
 - *Information is not generally available to fairly evaluate actual performance*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

271




Actual Performance

Example

- *The error (at 25 percent of scale and a 0°C ambient) associated with a temperature effect of 0.01% full scale per °C can be calculated as:*
 - *0.01*(20-0)/25, or 0.80% rate*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

272




Actual Performance

- *Velocity Profile*
 - *A few Coriolis mass flowmeters can be affected by a distorted velocity profile*
 - *Provide adequate straight run*
 - *Locate upstream/downstream elbows in recommended plane*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)


273



Actual Performance

- *Fluid Properties*
 - *Reference accuracy is determined using a known fluid at known conditions*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 274



Actual Performance

- *Fluid Properties*
 - *Variation from reference conditions may require calibration correlations that can affect flowmeter performance*
 - *Different fluid composition*
 - *Different fluid temperature*


Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 275



Flowmeter Performance

- *Flowmeter Performance*
- *Performance Statements*
- *Reference Performance*
- *Analog Output vs. Pulse Output*
- *Actual Performance*
- ***Supplier Claims***

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved) 276



Supplier Claims

- *High Turndown*
 - *Example - Hypothetical Coriolis mass flowmeter*
 - *0.10% rate accuracy*
 - *1000:1 turndown*
 - *Sounds fantastic!*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

277



Supplier Claims

- *High Turndown*
 - *Further investigation reveals that the accuracy is*
 - *0.10% rate plus zero stability*
 - *1000:1 turndown*
 - *Zero stability is small*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

278



Supplier Claims

- *High Turndown*
 - *Even more investigation reveals that the accuracy is*
 - *0.10% rate plus zero stability*
 - *1000:1 turndown*
 - *Zero stability is 0.025 kg/min (0-100 kg/min range)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

279



Reference Performance

- *High Turndown*
- *Performance expressed as a percent of rate degrades at low flows*
 - *100% flow → 0.125/100 0.13 % rate*
 - *25% flow → 0.050/25 0.20 % “*
 - *10% flow → 0.035/10 0.35 % “*
 - *1% flow → 0.026/1 2.60 % “*
 - *0.1% flow → 0.025/0.1 25.0 % “*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

280



Supplier Claims

- *High Turndown*
 - *Use of analog output would degrade performance even further*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

281



Supplier Claims

- *Low Flow Operation*
 - *Flowmeter operates at low flows, but performance expressed as a percent of rate is degraded*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

282




Supplier Claims

- *High Accuracy*
 - *High accuracy claims often refer to high flow rates that may not be practical*
 - *Zero stability is often hidden by omission*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

283




Supplier Claims

- *Improved Accuracy Claims*
 - *Trend to improve rate statement for better marketability*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

284




Supplier Claims

- *Improved Accuracy Claims*
 - *Compare zero stabilities to see whether the “improvement” is a restatement of the specifications*
 - *At least one supplier increasing zero stability to allow an “improvement” of the same flowmeter from 0.15 to 0.10% rate*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

285



Supplier Claims

- *Inexpensive Coriolis Mass Flowmeters*
 - *Less expensive*
 - *Fewer features*
 - *Not as accurate*
 - *Performance rivals other technologies*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

286



Seminar Outline

- *Introduction*
- *Fluid Flow Fundamentals*
- *Flowmeter Technology*
- *Flowmeter Performance*
- *Consumer Guide*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

287



Consumer Guide

User Equipment Selection Process

- *Learn about the technology*
- *Find suitable vendors*
- *Obtain specifications*
- *Organize specifications*
- *Evaluate specifications*
- *Select equipment*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

288




Consumer Guide

User Equipment Selection Process

- *Performing this process takes time and therefore costs money*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

289




Consumer Guide

User Equipment Selection Process

- *Haphazard implementation with limited knowledge of alternatives does not necessarily lead to a good equipment selection*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

290



Consumer Guide

Guide Provides First Four Items

- *Learn about the technology*
- *Find suitable vendors*
- *Obtain specifications*
- *Organize specifications*
- *Evaluate specifications*
- *Select equipment*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

291



Consumer Guide

Guide Provides First Four Items

- **Information focused on technology**
- **Comprehensive lists of suppliers and equipment**

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

292



Consumer Guide

Guide Provides First Four Items

- **Significant specifications**
- **Lists of equipment organized to facilitate evaluation**

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

293




Consumer Guide

User Equipment Selection Process

- **By providing the first four items, the Consumer Guides:**
 - **make technical evaluation and equipment selection easier, more comprehensive, and more efficient**

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

294




Consumer Guide

User Equipment Selection Process

- *By providing the first four items, the Consumer Guides:*
 - *allow selection from a larger number of suppliers*
 - *simplifies the overall selection process*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

295




Consumer Guide

- ***Supplier Data and Analysis***
- ***Attachments***
 - *Flowmeter categories*
 - *Availability of selected features*
 - *Models grouped by performance*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

296




Supplier Data and Analysis

- ***Flow Tube Limits***
 - *Size*
 - *1-300 mm*
 - *Ambient temperature*
 - *-20 to 60°C typical*
 - *NEMA 4X, IP65, 67*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

297



Supplier Data and Analysis

- *Flow Tube Limits*
 - *Wetted parts*
 - *Stainless steel*
 - *Hastelloy*
 - *Titanium*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

298



Supplier Data and Analysis

- *Flow Tube Limits*
 - *Some designs have seals*
 - *EPDM*
 - *Kalrez*
 - *PTFE*
 - *Viton*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

299



Supplier Data and Analysis

- *Flow Tube Limits*
 - *Geometry (and Orientation)*
 - *Self-filling*
 - *Self-draining*
 - *Self-filling and self-draining*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

300



Supplier Data and Analysis

- *Process Operating Limits*
 - *Pressure limit*
 - *1000 bar*
 - *Secondary containment*
 - *Temperature limit*
 - *200°C typical; 400°C max*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

301



Supplier Data and Analysis

- *Pressure Drop Limits*
 - *Damage flowmeter if excessive*
 - *Pressure drop increases with increasing viscosity*
 - *Flashing*
 - *Small amount causes unstable output*
 - *Large amount can stall tubes*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

302



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Straight run*
 - *Generally not required*
 - *Some designs need straight run*
 - *Examine installation instructions before purchase*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

303



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Supports*
 - *None with properly supported pipe*
 - *Two upstream and two downstream*
 - *Examine installation instructions before purchase*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

304



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Orientation*
 - *Self-filling (liquid)*
 - *Self-draining (gas/vapor)*
 - *Self-filling and self-draining*
 - *Examine literature and installation instructions before purchase*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

305



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Liquid - setting zero calibration*
 - *Remove all gas/vapor and zero*
 - *If not self-filling, remove gas/vapor by operating at high flow rate for a period of time*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

306



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Gas - setting zero calibration*
 - *Remove all liquid and zero*
 - *If not self-draining, remove liquid by operating at high flow rate for a period of time*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

307



Supplier Data and Analysis

- *Flow Tube Installation/Maintenance*
 - *Flow tube removal*
 - *Remove all liquid and remove from piping*
 - *If not self-draining, other procedures may be necessary to safely remove liquid*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

308



Supplier Data and Analysis

- *Flow Tube Operation*
 - *Start-up*
 - *If not self-filling, gas/vapor may be present*
 - *If not self-draining, liquid may be present*
 - *Undesired phase can be removed by operating at high flow rate for a period of time*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

309



Supplier Data and Analysis

- *Flow Tube Operation*
 - *Low flow*
 - *If not self-filling, gas/vapor may accumulate*
 - *If not self-draining, liquid may accumulate*
 - *Undesired phase can be removed by operating at high flow rate for a period of time*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

310



Supplier Data and Analysis

- *Transmitter*
 - *4-wire device (separate power/analog wires)*
 - *Using DC power can eliminate power conduit*
 - *Typically measure forward and reverse flow*
 - *Alarms, totalization, batching*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

311



Supplier Data and Analysis

- *Transmitter*
 - *Multivariable*
 - *Tube temperature*
 - *Fluid density*
 - *Fluid viscosity*
 - *Derived variables*
 - *Concentration*
 - *Volumetric flow*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

312



Supplier Data and Analysis

- *Transmitter*
 - *Mounting*
 - *Integral*
 - *Remote*
 - *Spacing (distance)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

313



Supplier Data and Analysis

- *Transmitter*
 - *Filtering is typically used*
 - *Excessive damping can affect batching response*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

314



Supplier Data and Analysis

- *Transmitter*
 - *Range adjustment mechanism provide insight into age of design*
 - *Analog (potentiometer)*
 - *Dip switch*
 - *Digital*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

315



Supplier Data and Analysis

- *Performance*
 - *Flow laboratory and flow calibration stand uncertainty is important to ensure that the flowmeter meets specifications when shipped*
 - *Formal (written) uncertainty analysis*
 - *Many suppliers could not quantify their uncertainty*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

316



Supplier Data and Analysis

- *Performance*
 - *Reference performance assumes that flowmeter is installed, calibrated, and operated properly*
 - *Pulse output accuracy is typically 0.10% rate plus zero stability*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

317



Supplier Data and Analysis

- *Performance*
 - *Analog output accuracy*
 - *Add 0.02 to 0.06% full scale*
 - *Some suppliers could not quantify*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

318



Supplier Data and Analysis

- *Performance*
 - *It can be difficult to compare the performance of different suppliers' equipment*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

319



Supplier Data and Analysis

- *Operating Effects*
 - *Ambient*
 - *Temperature, humidity*
 - *Process conditions*
 - *Temperature, pressure, viscosity, composition*
 - *Two-phase*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

320



Supplier Data and Analysis

- *Operating Effects*
 - *Other effects*
 - *Power supply voltage*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

321



Supplier Data and Analysis

- *Operating Effects*
 - *It can be difficult to compare the operating effects of different suppliers' equipment*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

322



Consumer Guide

- *Supplier Data and Analysis*
- *Attachments*
 - *Flowmeter categories*
 - *Availability of selected features*
 - *Models grouped by performance*
 - *Models grouped by supplier*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

323



Flowmeter Categories

- *Summary of offerings*
 - *Liquid*
 - *Gas*
 - *High Pressure*
 - *High Temperature*
 - *Metal (other than 316 stainless steel)*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

324




Flowmeter Categories

- *Summary of offerings*
 - *Plastic/Polymer*
 - *Sanitary*
 - *Single Path*
 - *Straight Path*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

325




Flowmeter Categories

- *Suppliers (21)*
- *Manufacturers (15)*
 - *7 USA*
 - *6 Germany*
 - *1 Brazil, Denmark, Japan, Mexico, Switzerland, UK*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

326




Availability of Selected Features

- *Use of seals*
- *Secondary containment*
- *IP67 housing*
- *Hazardous location approval*
- *Rigid support or frame recommended*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

327



Availability of Selected Features

- *Vertical piping*
 - *Self-filling and self-draining*
- *Horizontal piping*
 - *Self-filling*
 - *Self-draining*
 - *Self-filling and self-draining*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

328




Availability of Selected Features

- *Large size*
- *Batching*
- *Communications*
 - *HART*
 - *Foundation Fieldbus*
 - *Profibus*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

329



Availability of Selected Features

- *Less expensive design*
- *Two-phase flow*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

330



Models Grouped by Full Scale

- *0.003 kg/min and under*
- *0.01 kg/min*
- *0.03 kg/min*
- *0.1 kg/min*
- *0.3 kg/min*
- *1 kg/min*
- *3 kg/min*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

331



Models Grouped by Full Scale

- *10 kg/min*
- *30 kg/min*
- *100 kg/min*
- *300 kg/min*
- *1000 kg/min*
- *3000 kg/min*
- *10,000 kg/min*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

332



Review and Questions

- *Introduction*
- *Fluid Flow Fundamentals*
- *Flowmeter Technology*
- *Flowmeter Performance*
- *Consumer Guide*

Spitzer and Boyes, LLC (+1.845.623.1830)
Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)

333



The Consumer Guide to Coriolis Mass Flowmeters

*Seminar Presented by
David W. Spitzer
Spitzer and Boyes, LLC*

Copyright Copperhill and Pointer, Inc., 2004 (All Rights Reserved)